


Dusk



IMPORTANT SAFETY INSTRUCTIONS:

The following safety precautions should always be followed to reduce the risk of electric shock, personal injury or fire. It is important to read all these instructions carefully before using the product and to save them for future reference or new users.

- **Operating conditions:** rated maximum ambient temperature, $t_a = 25\text{ }^{\circ}\text{C}$
- **Electrical rating:** supply current, 0,6 A
- **Not suitable for outdoor use:** 
- **Nature of supply:** 3.7 V 

WARNING:

Before using the product, please read this manual carefully.

1. Children must not use this product without adult supervision
2. Do not expose the product to fire or high temperatures over $45\text{ }^{\circ}\text{C}$
3. Keep away from water, liquids, or wet areas. Do not soak in water or liquid.
4. Use a dry cloth to clean this product. Do not use chemicals on this product.
5. Make sure the product has plenty of ventilation during charging.
6. Do not try to repair or disassemble this product.
7. When the product is not in use, make sure it is correctly turned off and stored in a cool, dry place.
8. When disposing of this product. Do so responsibly, following local government requirements.
9. This device is designed for household use only. It is not suitable for commercial use.
10. The internal LEDs are not replaceable. When it reaches the end of its life, the whole base of the light will need replacing.
11. The rechargeable battery is permanently built into the product and cannot be replaced.
12. Never charge the rechargeable battery inside the product unattended.
13. If the product shows damage, it should be destroyed.
14. Only charge the product with an approved and suitable USB charger that complies with the requirements of the relevant standards.
15. When disposing of the product, please consult an electrician or your local authority to remove and dispose of the built-in batteries in an environmentally friendly manner.
16. Use the provided charging cable to charge the product only.
17. For non-replaceable light sources: "The light source of this luminaire is not replaceable; when the light source reaches its end of life, the whole luminaire shall be replaced".

WARNING: READ AND FOLLOW ALL ABOVE INSTRUCTIONS CAREFULLY. DO NOT DROP OR APPLY EXCESSIVE FORCE TO THIS PRODUCT. DO NOT EXPOSE TO HIGH TEMPERATURES. IMPROPER USE OR HANDLING OF THIS PRODUCT MAY RESULT IN FIRE OR EXPLOSION, CAUSING SERIOUS INJURY OR PROPERTY DAMAGE.

INSTRUCTIONS:

1. Use the provided charging cable to fully charge the unit before use.
2. The LED indicator will be red during charging, and after it is fully charged, it will turn green.
3. Disconnect the USB-C cable after charging (LED indicator changed to green).
4. Touch the power on/off switch to switch the unit on and off. Touch control with 3 brightness levels.
5. If the light becomes dim or unstable, you may need to recharge the unit.
6. Fully charging time is (4-6 hours approx)...operation is 10 hours approx after the battery is fully charged. Operation time will be reduced after a period of use.